

Scilab Textbook Companion for  
Microwave Engineering  
by M. Kulkarni<sup>1</sup>

Created by  
Karan Bhargava  
B.Tech  
Electronics Engineering  
Uttarakhand Technical University  
College Teacher  
Vatsalya Sharma  
Cross-Checked by  
Madhu N. Belur

August 10, 2013

<sup>1</sup>Funded by a grant from the National Mission on Education through ICT, <http://spoken-tutorial.org/NMEICT-Intro>. This Textbook Companion and Scilab codes written in it can be downloaded from the "Textbook Companion Project" section at the website <http://scilab.in>

# Book Description

**Title:** Microwave Engineering

**Author:** M. Kulkarni

**Publisher:** Umesh Publications, New Delhi

**Edition:** 1

**Year:** 2011

**ISBN:** 81-88114-26-X

Scilab numbering policy used in this document and the relation to the above book.

**Exa** Example (Solved example)

**Eqn** Equation (Particular equation of the above book)

**AP** Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

# Contents

List of Scilab Codes	4
3 Transmission Lines	9
4 Microwaves Transmission Lines	18
5 Cavity Resonators	39
6 Microwave Components	43
7 Microwave Measurements	52
8 Microwave Tubes and Circuits	55
9 Solid State Microwave Devices	71

# List of Scilab Codes

Exa 3.1	Program to find value of terminating impedance of lossless transmission line . . . . .	9
Exa 3.2	Calculate the characteristic impedance and attenuation constant and phase constant of transmission line and Calculate power delivered to load if line length is 500 km	9
Exa 3.3	Calculate phase velocity of the wave that propogates on line . . . . .	11
Exa 3.4	Calculate Current drawn from generator and Magnitune and phase of load current and Power delivered to load	11
Exa 3.5	Calculate VSWR and reflection coefficient . . . . .	12
Exa 3.6	Determine point of attachment and length of stub . . .	13
Exa 3.7	Calculate terminating impedance . . . . .	14
Exa 3.8	Determine the VSWR and Position of 1st Vmin to Vmax and Vmin and Vmax and Impedance at Vmin and Vmax	14
Exa 3.9	Determine in dB the reflection loss and transmission line and return loss . . . . .	15
Exa 3.10	Calculate the charcterstic impedance and phase velocity	16
Exa 4.1	Calculate the inductance per unit length and capacitance per unit length and characteristic impedance and velocity of propagation . . . . .	18
Exa 4.2	Calculate the attenuation and phase constants and phase velocity and relative permittivity and power loss . . . .	19
Exa 4.3	Calculate the breakdown power of air filled coaxial cable	20
Exa 4.4	Calculate characteristic impedance and velocity of propagation . . . . .	20
Exa 4.5	Calculate characteristic impedance and effective dielectric constant and velocity of propagation . . . . .	21

Exa 4.6	Calculate ratio of circular waveguide crosssectional area to rectangular waveguide crosssection . . . . .	22
Exa 4.7	Calculate breadth of rectangular waveguide . . . . .	23
Exa 4.8	Calculate the cutoff wavelength and guide wavelength and group and phase velocities . . . . .	24
Exa 4.9	Calculate the possible modes and cutoff frequencies and guide wavelength . . . . .	25
Exa 4.10	Calculate the required size of guide and frequencies that can be used for this mode of propagation . . . . .	25
Exa 4.11	Find all modes that can propagate at 5000MHz . . . . .	26
Exa 4.12	Calculate the cutoff wavelength and cutoff frequency and wavelength in guide . . . . .	27
Exa 4.13	Calculate the frequency of the wave . . . . .	28
Exa 4.14	Calculate the guide wavelength and phase constant and phase velocity for dominant mode . . . . .	29
Exa 4.15	Calculate what modes propagate at free space wavelength of 10 cm and 5 cm . . . . .	30
Exa 4.16	Determine the characteristic wave impedance . . . . .	31
Exa 4.17	Determine the diameter of waveguide and guide wavelength . . . . .	32
Exa 4.18	Show TE <sub>01</sub> mode propagates under given conditions . . . . .	33
Exa 4.19	Calculate the amount of attenuation if signal of frequency is 6GHz . . . . .	34
Exa 4.20	Calculate the maximum power handling capacity . . . . .	35
Exa 4.21	Calculate the maximum power . . . . .	35
Exa 4.22	Calculate the peak value of electric feild occuring in the waveguide . . . . .	36
Exa 4.23	Calculate the breakdown power of air filled rectangular waveguide for dominant mode . . . . .	37
Exa 4.24	Calculate the breakdown power of circular waveguide . . . . .	37
Exa 5.1	Determine the minimum distance between two end plates . . . . .	39
Exa 5.2	Calculate the lowest frequency of a rectangular cavity resonator . . . . .	40
Exa 5.3	Calculate the resonant frequency of a circular cavity resonator . . . . .	40
Exa 5.4	Calculate the resonant frequency of a circular cavity resonator . . . . .	41

Exa 6.2	Find the distance that the position of port 1 should be shifted . . . . .	43
Exa 6.3	Determine the scattering parameters for 10 dB direction coupler . . . . .	44
Exa 6.4	Determine the powers in the remaining ports . . . . .	45
Exa 6.5	Determine the powers in the remaining ports . . . . .	45
Exa 6.6	Determine the powers reflected at port 3 and power divisions at other ports . . . . .	46
Exa 6.7	Calculate the scattering matrix . . . . .	47
Exa 6.9	Calculate the scattering matrix . . . . .	48
Exa 6.10	Calculate the scattering matrix . . . . .	48
Exa 6.11	Calculate the directivity and coupling and isolation . . . . .	49
Exa 6.12	Calculate the value of VSWR . . . . .	50
Exa 6.13	Calculate the phase shift of the component . . . . .	50
Exa 7.1	Calculate the SWR of the transmission line . . . . .	52
Exa 7.2	Calculate the SWR of the main waveguide . . . . .	53
Exa 7.3	Calculate the SWR of the waveguide . . . . .	53
Exa 7.4	Calculate the value of reflected power . . . . .	54
Exa 8.1	Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density . . . . .	55
Exa 8.2	Calculate the input rms voltage and output rms voltage and power delivered to load . . . . .	56
Exa 8.3	Calculate the input power in watts and output power in watts and efficiency . . . . .	57
Exa 8.4	Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB . . . . .	58
Exa 8.5	Calculate the input microwave voltage and voltage gain and efficiency of amplifier and beam loading conductance . . . . .	58
Exa 8.6	Calculate the value of repeller voltage and beam current necessary to give gap voltage of 200V and electronic efficiency . . . . .	60
Exa 8.7	Calculate the efficiency of reflex klystron and total output power in mW and power delivered to load . . . . .	61

Exa 8.8	Calculate the Hull cutoff voltage and cutoff magnetic flux density if beam voltage is 6000V and cyclotron frequency in GHz . . . . .	62
Exa 8.9	Calculate the Axial phase velocity and Anode voltage at which TWT can be operated for useful gain . . . . .	63
Exa 8.10	Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB . . . . .	63
Exa 8.11	Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density . . . . .	64
Exa 8.12	Calculate the gap transit angle . . . . .	65
Exa 8.13	Calculate the input rf voltage and voltage gain and efficiency . . . . .	66
Exa 8.14	Calculate the cyclotron angular frequency and cutoff voltage and cutoff magnetic flux . . . . .	67
Exa 8.15	Calculate the input power and output power in watts and efficiency . . . . .	68
Exa 8.16	Calculate the repeller voltage and beam current necessary to give gap voltage of 200V . . . . .	69
Exa 9.1	Calculate i repeller voltage $V_r$ ii beam current necessary to give gap voltage of 200V . . . . .	71
Exa 9.2	Determine threshold electric field . . . . .	71
Exa 9.3	Calculate the power gain in dB and power gain if it is USB converter . . . . .	72
Exa 9.4	Calculate the critical voltage and breakdown voltage and breakdown electric field . . . . .	73
Exa 9.5	Calculate the power gain in dB and power gain if it is USB converter . . . . .	73
Exa 9.6	Calculate the power gain in dB . . . . .	74
Exa 9.7	Calculate the minimum voltage needed to GUNN effect . . . . .	74
Exa 9.8	Calculate the rational frequency and critical velocity of diode . . . . .	75
Exa 9.9	Calculate the resonant frequency and efficiency . . . . .	76
Exa 9.10	Calculate the drift time of carrier and operating frequency of diode . . . . .	76



Exa 9.11	Calculate the breakdown voltage and breakdown electric field . . . . .	77
Exa 9.12	Calculate the maximum power gain and noise figure and bandwidth . . . . .	78
Exa 9.13	Calculate the equivalent noise resistance and gain and noise figure and bandwidth . . . . .	79

# Chapter 3

## Transmission Lines

**Scilab code Exa 3.1** Program to find value of terminating impedance of lossless transmission line

```
1 //Caption:Program to find value of terminating
   impedance of lossless transmission line.
2 //Exa:3.1
3 clc;
4 clear;
5 close;
6 //Given:
7 Z_ch=100;//in ohms
8 S=5;//VSWR (unitless)
9 Z=Z_ch*S;
10 printf("\\n\\n\\t The terminating impedance = %d ohms "
   ,Z);
```

---

**Scilab code Exa 3.2** Calculate the characteristic impedance and attenuation constant and phase constant of transmission line and Calculate power delivered to load if line length is 500 km

```

1 //Caption:Calculate the characteristic impedance,
   attenuation constant, phase constant of
   transmission line Calculate power delivered to
   load , if line length=500 km.
2 //Exa:3.2
3 clc;
4 clear;
5 close;
6 e=2.718;
7 //Given:
8 R=8;//in ohm/kilometer
9 L=2*10^-3;//in henry/kilometer
10 C=0.002*10^-6;//in farad/kilometer
11 G=0.07*10^-6;//second/kilometer
12 f=2000;//in hertz
13 //Since [w=2*(pi)*f] & [Zch={(R+jwL)/(G+jwC)}^0.5]
14 w=2*%pi*f;//in radians
15 Z_ch={(R+%i*w*L)/(G+%i*w*C)}^0.5;//computing
   characteristic impedance
16 disp(Z_ch,"Characteristic impedance (in ohms) =");
17 y={(R+%i*w*L)*(G+%i*w*C)}^0.5;
18 a=real(y);//atteneuation constant
19 b=imag(y);//phase constant
20 disp(a,"Atteneuation constant (in NP/km) =");
21 disp(b,"Phase constant (in radian/km) =");
22 V_in=2;//in volts
23 l=500;//in kilometers
24 Z_in=Z_ch;//Since line terminated at its char. imped
   . so, Z_in=Z_ch=Z(load)
25 I_s=V_in/Z_in;
26 Imag=[[{real(I_s)}^2]+[{imag(I_s)}^2]]^0.5]*10^3;//
   in milliampere
27 Iang=atan(imag(I_s)/real(I_s))*(180/%pi);//in
   degrees

```

```

28 I=Imag*e^-1.99; //I=Is*e^-yl
29 //P(power delivered)=I*I*REAL(Z_ch)
30 P=I*I*real(Z_ch);
31 disp(P,"Power delivered to load (in microwatt =)");

```

---

**Scilab code Exa 3.3** Calculate phase velocity of the wave that propagates on line

```

1 //Caption:Calculate phase velocity of the wave that
   propogates on line as given in example 3.2
2 //Exa:3.3
3 clc;
4 clear;
5 close;
6 w=4*pi*10^3; //in rad/sec
7 b=0.02543; //in rad/km
8 V_p=w/b; // phase velocity
9 disp(V_p,"Phase velocity (in km/sec) =");

```

---

**Scilab code Exa 3.4** Calculate Current drawn from generator and Magnitude and phase of load current and Power delivered to load

```

1 //Caption:Calculate (a)–Current drawn from generator
   . (b)–Magnitune & phase of load current. (c)–
   Power delivered to load.

```

```

2 //Exa: 3.4
3 clc;
4 clear;
5 close;
6 f=37.5*10^6; //frequency(in hertz)
7 wl=(3*10^8)/f; //wavelength (in meters)
8 Z_l=100; //in ohms
9 Z_o=200; //in ohms
10 l=5*wl/4; //length of line (in meters)
11 b=2*%pi/wl;
12 //At generator end,
13 Z_i=Z_o*(Z_l+%i*Z_o*tan(b*l))/(Z_o+%i*Z_l*tan(b*l));
14 V_s=200*Z_i/(200+Z_i);
15 I_s=200/(200+Z_i);
16 disp(real(I_s),"Current drawn from generator(in amps
    ) =");
17 //for a lossless line , P(avg)*I_input=P(avg)*I_load
18 P_avg=V_s*I_s; //in watts
19 disp(real(P_avg),"Power delivered to load (in watts
    =)");
20 //Real(Vs*Is)=Real(Vs*I_load)
21 I_load=(P_avg/Z_l)^0.5; //in amps
22 disp(real(I_load),"Current flowing in load (in amps
    =)");

```

---

**Scilab code Exa 3.5** Calculate VSWR and reflection coefficient

```

1 //Caption: Calculate VSWR & reflection coefficient.
2 //Exa: 3.5
3 clc;
4 clear;

```

```

5  close;
6  Z_o=50; //in ohms
7  f=300*10^6; //in Hz
8  Z_l=50+%i*50; //in ohms
9  wl=(3*10^8)/f; //wavelength(in meters)
10 P=[(Z_l-Z_o)/(Z_l+Z_o)];
11 P_mag={real(P)^2+(imag(P)^2)^0.5;
12 P_ang=atan(imag(P)/real(P))*180/%pi; //in degrees
13 S={1+P_mag}/{1-P_mag};
14 disp(P,"Reflection coefficient =");
15 disp(P_mag,"Magnitude of reflection coefficient =");
16 disp(P_ang,"Angle (in degree) =");
17 disp(S,"VSWR =");

```

---

**Scilab code Exa 3.6** Determine point of attachment and length of stub

```

1  //Caption:Determine point of attachment & length of
   stub.
2  //Exa 3.6
3  clc;
4  clear;
5  close;
6  Z_l=100; //in ohms
7  Z_o=600; //in ohms
8  f=100*10^6; //in Hz
9  wl=(3*10^8)/f;
10 //Position of stub is :
11 m=((Z_l*Z_o)/(Z_l-Z_o))^0.5;
12 pos={wl/(2*%pi)}*atan((Z_l/Z_o)^0.5); //in meters
13 l={wl/(2*%pi)}*{atan(m)}; //in meters
14 disp(pos,"Position of stub (in meters) =");

```

```
15 disp(abs(1),"Length of stub (in meters) =");
```

---

**Scilab code Exa 3.7** Calculate terminating impedance

```
1 //Caption: Calculate terminating impedance.
2 //Exa: 3.7
3 clc;
4 clear;
5 close;
6 Z_o=50;
7 S=3.2;
8 X_min=0.23;//in terms of wavelength(wl)
9 //So :
10 Z_1=Z_o*[[1-%i*S*tan(2*%pi*X_min)],[S-%i*tan(2*%pi*
    X_min)]];//in ohms
11 Z_1mag=[(real(Z_1)^2)+(imag(Z_1)^2)]^0.5;
12 Z_1lang=atan(imag(Z_1)/real(Z_1));
13 disp("The load impedance");
14 disp(Z_1mag,"magnitude (in ohms) =");
15 disp(Z_1lang*180/%pi,"angle (in degrees) =");
```

---

**Scilab code Exa 3.8** Determine the VSWR and Position of 1st Vmin to Vmax and Vmin and Vmax and Impedance at Vmin and Vmax

```

1 //Caption:Determine:(a)VSWR; (b)Position of 1st Vmin
    & Vmax; (c)Vmin & Vmax; (d)Impedance at Vmin &
    Vmax.
2 //Exa: 3.8
3 clc;
4 clear;
5 close;
6 Z_o=50;//in ohms
7 Z_l=100;//in ohms
8 f=300*10^3;//in Hz
9 P_l=50*10^-3;//in watts
10 wl=(3*10^8)/f;
11 p=(Z_l-Z_o)/(Z_l+Z_o);
12 S=(1+abs(p))/(1-abs(p));
13 disp(S,"VSWR =");
14 //Since real Zl > Zo ,
15 pos=wl/4;
16 disp("First Vmax is located --->at the load ");
17 disp("First Vmin is located at --->(wavelength/4)= "
    );
18 disp(pos,"(in meters)");
19 V_max=(P_l*Z_l)^0.5;
20 V_min=V_max/S;
21 disp(V_max,"Vmax (in volts) =");
22 disp(V_min,"Vmin (in volts) =");
23 disp(Z_o/S,"Zin at Vmin (in ohms) =:");
24 disp(Z_o*S,"Zin at Vmax (in ohms) =");

```

---

**Scilab code Exa 3.9** Determine in dB the reflection loss and transmission line and return loss



```

1 //Caption:Determine in dB: (a)-reflection loss , (b)-
  transmission line (c)-return loss .
2 //Exa: 3.9
3 clc;
4 clear;
5 close;
6 Z_o=600;//in ohm
7 Z_s=50;//in ohm
8 l=200;//in meter
9 Z_l=500;//in ohm
10 p=(Z_l-Z_o)/(Z_l+Z_o);
11 ref_los=10*(log(1/(1-(abs(p))^2)))/(log(10));//in dB
12 disp(ref_los,"Reflection loss (in dB) =");
13 //attenuation loss= 0 dB
14 //Transmisson loss = (attenuation loss)+(reflection
  loss) = (reflection loss)
15 tran_los=ref_los;
16 disp(tran_los,"Transmisson loss (in dB) =");
17 ret_los=10*(log(abs(p)))/(log(10));
18 disp(ret_los,"Return loss(in dB) =");

```

---

**Scilab code Exa 3.10** Calculate the charcterstic impedance and phase velocity

```

1 //Caption:Calculate the charcterstic impedance &
  phase velocity
2 //Exa:3.10
3 clc;
4 clear;
5 close;
6 e=2.718;

```

```

7 f=1000; //in Hz
8 l=10000; //in meters
9 Z_sc=(2631+%i*1289); //in ohms
10 Z_oc=(221-%i*137); //in ohms
11 Z_o=[Z_sc*Z_oc]^0.5;
12 Z_mag=[real(Z_o)^2+imag(Z_o)^2]^0.5;
13 Z_ang=[atan((imag(Z_o))/real(Z_o))]*180/%pi;
14 disp(Z_mag," Characteristic impedance (in ohms) =");
15 disp(Z_ang," Angle (in degrees) =");
16 x=[(Z_oc/Z_sc)^0.5];
17 //x=tanh(v*l)
18 //As, tanh(t)=[e^t-e^-t]/[e^t+e^-t]
19 v=(261+%i*2988)/l;
20 a=real(v);
21 b=imag(v);
22 disp(2*%pi*f/b," Phase velocity (in meter per sec.) =
    ");

```

---

# Chapter 4

## Microwaves Transmission Lines

**Scilab code Exa 4.1** Calculate the inductance per unit length and capacitance per unit length and characteristic impedance and velocity of propagation

```
1 //Caption: Calculate (i)-inductance per unit length ,(
    ii)-capacitance per unit length ,(iii)-
    characteristic impedance ,(iv)-velocity of
    propagation
2 //Exa:4.1
3 clc;
4 clear;
5 close;
6 //Given:
7 d=0.49; //in cm
8 D=1.1; //in cm
9 e_r=2.3;
10 c=3*10^8; //in meter/second
11 L=2*(10^-7)*log(D/d); //in Henry/meter
12 C=55.56*(10^-12)*(e_r)/log(D/d); //in farad/meter
13 R_o=(60/sqrt(e_r)) *log(D/d); //in ohms
14 v=c/sqrt(e_r); //in meter/second
15 disp(L, 'Inductance per unit length (in H/m) =');
16 disp(C, 'Capacitance per unit length (in F/m) =');
17 disp(R_o, 'Characteristic Impedance (in ohms) =');
```

```
18 disp(v, 'Velocity of propagation (in m/s)=');
```

---

**Scilab code Exa 4.2** Calculate the attenuation and phase constants and phase velocity and relative permittivity and power loss

```
1 //Caption: Calculate the attenuation , phase constants
   , phase velocity , relative permittivity , power loss .
2 //Exa:4.2
3 clc;
4 clear;
5 close;
6 R=0.05; //in ohms
7 G=0;
8 l=50; //in meter
9 e=2.3; //dielectric constant
10 c=3*10^8; //in m/s
11 L=2*(10^-7); //from Exa:4.1
12 C=1.58*(10^-10); //from Exa:4.1
13 P_in=480; //in watts
14 f=3*10^9; //in hertz
15 Z_o=sqrt(L/C);
16 a=R/Z_o; //in Np/m
17 b=2*pi*f*sqrt(L*C); //in rad/m
18 V_p=1/sqrt(L*C);
19 e_r=(c/V_p)^2;
20 P_loss=P_in*2*l;
21 disp(a, 'Atteneuation (in Np/m) =');
22 disp(b, 'Phase constant (in rad/m) =');
23 disp(V_p, 'Phase velocity (in m/s) =');
24 disp(e_r, 'Relative permittivity =');
25 disp(P_loss, 'Power loss (in watts) =');
```

---

**Scilab code Exa 4.3** Calculate the breakdown power of air filled coaxial cable

```
1 //Caption: Calculate the breakdown power of air
   filled coaxial cable at 9.375 GHz.
2 //Exa:4.3
3 clc;
4 clear;
5 close;
6 //Given:
7 a=2.42; //in cm
8 x=2.3; //x=(b/a)
9 P_bd=3600*a^2*log(x); //in kilowatts
10 disp(P_bd, 'Breakdown Power (in kW) =');
11
12 //answer in book is wrongly written as 398 kW.
```

---

**Scilab code Exa 4.4** Calculate characteristic impedance and velocity of propagation

```
1 //Caption: Calculate characteristic impedance &
   velocity of propagation.
2 //Exa:4.4
3 clc;
```

```

4 clear;
5 close;
6 b=0.3175; //in cm
7 d=0.0539; //in cm
8 c=3*10^8; //in m/s
9 e_r=2.32;
10 Z_o=60*log(4*b/(%pi*d))/sqrt(e_r); //in ohms
11 V_p=c/sqrt(e_r); //in m/s
12 disp(Z_o, 'Characteristic impedance (in ohms) =');
13 disp(V_p, 'Velocity of propagation (in m/s) =');

```

---

**Scilab code Exa 4.5** Calculate characteristic impedance and effective dielectric constant and velocity of propagation

```

1 //Caption: Calculate characteristic impedance &
   effective dielectric constant & velocity of
   propagation
2 //Exa:4.5
3 clc;
4 clear;
5 close;
6 e_r=9.7;
7 c=3*10^8; //in m/s
8 r_1=0.5; //when ratio: (W/h)=0.5
9 r_2=5; //when ratio: (W/h)=5
10 //For W/h ratio=0.5
11 e_eff_1=(e_r+1)/2+((e_r-1)/2)*[1/{sqrt(1+12*(1/r_1))
   +0.04*(1-r_1)}];
12 Z_o_1=60*log(8/r_1+r_1/4)/sqrt(e_eff_1);
13 v_1=c/sqrt(e_eff_1);
14 disp(" For W/h=0.5  ,");

```

```

15 disp(e_eff_1,'Effective dielectric constant =');
16 disp(Z_o_1,'Characteristic impedance (in ohms) =');
17 disp(v_1,'Velocity of propagation (in m/s) =');
18 //For W/h ratio=5
19 e_eff_2=(e_r+1)/2+((e_r-1)/2)*[1/{sqrt(1+12*(1/r_2))
    }];
20 Z_o_2=120*%pi*[1/{r_2+1.393+0.667*log(1.444+r_2)}]/
    sqrt(e_eff_2);
21 v_2=c/sqrt(e_eff_2);
22 disp("For W/h=5,");
23 disp(e_eff_2,'Effective dielectric constant =');
24 disp(Z_o_2,'Characteristic impedance (in ohms) =');
25 disp(v_2,'Velocity of propagation (in m/s) =');

```

---

**Scilab code Exa 4.6** Calculate ratio of circular waveguide crosssectional area to rectangular waveguide crosssection

```

1 //Caption:Calculate ratio of circular waveguide
    cross-sectional area to rectangular waveguide
    cross-section
2 //Exa:4.6
3 clc;
4 clear;
5 close;
6 //For TE Wave propagated:
7 //for Rectangular , taking (a=2b)
8 r=100;//assume
9 //for TE11, wavelength=2*pi*r/1.841
10 //for TE10, wavelength=2a
11 a=(2*%pi*r/1.841)/2;
12 ar_rec_TE=(a)*(a/2);

```

```

13 ar_cir_TE=%pi*r^2;
14 ratio_TE=(ar_cir_TE)/(ar_rec_TE);
15 disp(ratio_TE,'Ratio of Circular & Rectangular coss-
    section area (in TE) =');
16 //For TM Wave propagated:
17 //for Rectangular , taking (a=2b)
18 //for TE01, wavelength=2.6155*r
19 //for TE11, wavelength=4b/sqrt(5)
20 b=(2.6155*r)/1.78885;
21 ar_rec_TM=(b)*(b);
22 ar_cir_TM=%pi*r^2;
23 ratio_TM=(ar_cir_TM)/(ar_rec_TM);
24 disp(ratio_TM,'Ratio of Circular & Rectangular coss-
    section area (in TM) =');

```

---

**Scilab code Exa 4.7** Calculate breadth of rectangular waveguide

```

1 //Caption: Calculate breadth of rectangular waveguide
2 //Exa:4.7
3 clc;
4 clear;
5 close;
6 f=9*10^9; //in Hz
7 c=3*10^10; //in cm/s
8 wl_g=4; //in m
9 wl_o=c/f;
10 wl_c=[sqrt(1-((wl_o/wl_g)^2))/wl_o]^(-1);
11 b=wl_c/4;
12 disp(b,'Breadth of rectangular waveguide (in cm) =')
    ;

```

---



**Scilab code Exa 4.8** Calculate the cutoff wavelength and guide wavelength and group and phase velocities

```
1 //Caption: Calculate the cutoff wavelength, guide
   wavelength, group & phase velocities
2 //Exa:4.8
3 clc;
4 clear;
5 close;
6 a=10; //in cm
7 c=3*10^10; //in cm/s
8 wl_c=2*a; //in cm
9 f=2.5*10^9; //in Hz
10 wl_o=c/f;
11 wl_g=wl_o/(sqrt(1-(wl_o/wl_c)^2)); //in cm
12 V_p=c/(sqrt(1-(wl_o/wl_c)^2));
13 V_g=c^2/V_p;
14 disp(wl_c, 'Cut-off wavelength (in cm) =');
15 disp(wl_g, 'Guide wavelength (in cm) =');
16 disp(V_p, 'Phase velocity (in cm/s) =');
17 disp(V_g, 'Group velocity (in cm/s) =');
```

---

**Scilab code Exa 4.9** Calculate the possible modes and cutoff frequencies and guide wavelength

```
1 //Caption: Calculate (i)-possible modes,(ii)-cut-off
    frequencies ,(iii)-guide wavelength
2 //Exa:4.9
3 clc;
4 clear;
5 close;
6 //For TE mode:
7 a=2.5;//in cm
8 b=1;//in cm
9 f=8.6*10^9;//in Hz
10 c=3*10^10;//in cm/s
11 wl_o=c/f;
12 wl_c_1=2*b;//for TE01
13 wl_c_2=2*a;//for TE10
14 disp( 'Only TE10 mode is possible ');
15 f_c=c/wl_c_2;
16 wl_c_3=2*a*b/sqrt(a^2+b^2);//for TE11 & TM11
17 wl_g_TE10=wl_o/(sqrt(1-(wl_o/wl_c_2)^2));//for TE10
18 disp(f_c, 'Cut-off frequency (in Hz) =');
19 disp(wl_g_TE10, 'Guide wavelength for TE10 (in cm) ='
    );
20 //For TM mode:
21 disp('TM11 also propagates');
22 wl_c_TM11=wl_c_3;
23 wl_g_TM11=wl_o/(sqrt(1-(wl_o/wl_c_2)^2));//for TM11
24 disp(wl_g_TM11, 'Guide wavelength for TM11 (in cm) ='
    );
```

---

**Scilab code Exa 4.10** Calculate the required size of guide and frequencies that can be used for this mode of propagation

```

1 //Caption: Calculate (i)-required size of guide ,(ii)-
    frequencies that can be used for this mode of
    propagation
2 //Exa:4.10
3 clc;
4 clear;
5 close;
6 wl_c=10; //in cm
7 c=3*10^10; //in cm/s
8 r=wl_c/(2*%pi/1.841); //in cm
9 area=%pi*r^2; //in sq. cm
10 f_c=c/wl_c;
11 disp(r, 'Radius of circular waveguide(in cm) =');
12 disp(area, 'Area of cross-section of circular
    waveguide(in cm) =');
13 disp('Frequency above');
14 disp(f_c);
15 disp('can be propagated');

```

---

**Scilab code Exa 4.11** Find all modes that can propagate at 5000MHz

```

1 //Caption: Find all modes that can propagate at 5000
    MHz.
2 //Exa:4_11
3 clc;
4 clear;
5 close;
6 a=4; //in cm
7 b=3; //in cm
8 f=5*10^9; //in Hz
9 c=3*10^10; //in cm/s

```

```

10 wl_o=c/f;
11 //For TE waves:
12 wl_c_TE01=2*b;//for TE01
13 wl_c_TE10=2*a;//for TE10
14 wl_c_TE11=2*a*b/sqrt(a^2+b^2);//for TE11
15 if(wl_c_TE01>wl_o)
16     disp('TE01 can propagate');
17 else
18     disp('TE01 cannot propagate');
19 end
20 if(wl_c_TE10>wl_o)
21     disp('TE10 can propagate');
22 else
23     disp('TE10 cannot propagate');
24 end
25 if(wl_c_TE11>wl_o)
26     disp('TE11 can propagate');
27 else
28     disp('TE11 cannot propagate');
29 end

```

---

**Scilab code Exa 4.12** Calculate the cutoff wavelength and cutoff frequency and wavelength in guide

```

1 //Caption:Find all modes that can propagate at 5000
  MHz.
2 //Exa:4_11
3 clc;
4 clear;
5 close;
6 a=4;//in cm

```

```

7 b=3; //in cm
8 f=5*10^9; //in Hz
9 c=3*10^10; //in cm/s
10 wl_o=c/f;
11 //For TE waves:
12 wl_c_TE01=2*b; //for TE01
13 wl_c_TE10=2*a; //for TE10
14 wl_c_TE11=2*a*b/sqrt(a^2+b^2); //for TE11
15 if(wl_c_TE01>wl_o)
16     disp('TE01 can propagate');
17 else
18     disp('TE01 cannot propagate');
19 end
20 if(wl_c_TE10>wl_o)
21     disp('TE10 can propagate');
22 else
23     disp('TE10 cannot propagate');
24 end
25 if(wl_c_TE11>wl_o)
26     disp('TE11 can propagate');
27 else
28     disp('TE11 cannot propagate');
29 end

```

---

**Scilab code Exa 4.13** Calculate the frequency of the wave

```

1 //Caption: Calculate (i)-cutoff wavelength,(ii)-
    cutoff frequency,(iii)-wavelength in guide
2 //Exa:4.12
3 clc;
4 clear;

```

```

5  close;
6  c=3*10^10; //in cm/s
7  d=4; //in cm
8  r=d/2; //in cm
9  wl_c=2*%pi*r/1.841; //in cm
10 f_c=c/wl_c;
11 f_signal=5*10^9; //in Hz
12 wl_o=c/f_signal;
13 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
14 disp(wl_c, 'Cut-off wavelength (in cm) =');
15 disp(f_c, 'Cut-off frequency (in Hz) =');
16 disp(wl_g, 'Guide wavelength (in cm) =');

```

---

**Scilab code Exa 4.14** Calculate the guide wavelength and phase constant and phase velocity for dominant mode

```

1  //Caption: Calculate (i)-guide wavelength, (ii)-phase
    constant, (iii)-phase velocity for dominant mode
2  //Exa:4.14
3  clc;
4  clear;
5  close;
6  c=3*10^10; //in cm/s
7  a=5; //in cm
8  b=2.5; //in cm
9  wl_o=4.5; //in cm
10 //For TE10 mode:
11 wl_c=2*a;
12 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
13 V_p=c/sqrt(1-(wl_o/wl_c)^2);
14 w=2*%pi*c/wl_o;

```

```

15 w_c=2*%pi*c/wl_c;
16 b=sqrt(w^2-w_c^2)/c;
17 disp(wl_g, 'Guide wavelength (in cm) =');
18 disp(b, 'Phase constant =');
19 disp(V_p, 'Phase velocity (in cm/s) =');
20
21 //answer in book is wrongly written as guide
    wavelength =7.803 cm
22 //answer in book is wrongly written as Phase
    velocity = 5.22*10^10 cm/s

```

---

**Scilab code Exa 4.15** Calculate what modes propagate at free space wavelength of 10 cm and 5 cm

```

1 //Caption: Calculate what modes propagate at free
    space wavelength of (i)10 cm,(ii)5 cm
2 //Exa:4.15
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 wl_c_TE10=16; //Critical wavelength of TE10
8 wl_c_TM11=7.16; //Critical wavelength of TM11
9 wl_c_TM21=5.6; //Critical wavelength of TM21
10 //For (i): 10 cm
11 wl_o=10; //in cm
12 disp(wl_o, 'For free space wavelength (in cm) =');
13 if(wl_c_TE10>wl_o)
14     disp('    TE10 can propagate');
15 else
16     disp('    TE10 cannot propagate');

```

```

17 end
18 if(wl_c_TM11>wl_o)
19     disp('    TM11 can propagate');
20 else
21     disp('    TM11 cannot propagate');
22 end
23 if(wl_c_TM21>wl_o)
24     disp('    TM21 can propagate');
25 else
26     disp('    TM21 cannot propagate');
27 end
28 //For (ii): 5 cm
29 wl_o=5;//in cm
30 disp(wl_o,'For free space wavelength (in cm) =');
31 if(wl_c_TE10>wl_o)
32     disp('    TE10 can propagate');
33 else
34     disp('    TE10 cannot propagate');
35 end
36 if(wl_c_TM11>wl_o)
37     disp('    TM11 can propagate');
38 else
39     disp('    TM11 cannot propagate');
40 end
41 if(wl_c_TM21>wl_o)
42     disp('    TM21 can propagate');
43 else
44     disp('    TM21 cannot propagate');
45 end

```

---

**Scilab code Exa 4.16** Determine the characteristic wave impedance



```

1 //Caption:Determine the charcteristic wave impedance
2 //Exa:4.16
3 clc;
4 clear;
5 close;
6 c=3*10^10;//in cm/s
7 f=10*10^9;//in Hz
8 a=3;//in cm
9 b=2;//in cm
10 n=120*%pi;
11 wl_o=c/f;
12 wl_c=2*a*b/sqrt(a^2+b^2);
13 Z_TM=n*sqrt(1-(wl_o/wl_c)^2);
14 disp(Z_TM,'Characteristic impedance (in ohms) =');
15
16 //answer in book is wrongly written as 61.618 ohms

```

---

**Scilab code Exa 4.17** Determine the diameter of waveguide and guide wavelength

```

1 //Caption:Determine the diameter of waveguide &
   guide wavelength
2 //Exa:4.17
3 clc;
4 clear;
5 close;
6 c=3*10^10;//in cm/s
7 f=6*10^9;//in Hz
8 f_c=0.8*f;

```

```

9 wl_c=c/f_c;
10 D=1.841*wl_c/%pi;
11 wl_o=c/f;
12 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
13 disp(D,'Diameter of waveguide (in cm) =');
14 disp(wl_g,'Guide wavelength (in cm) =');

```

---

**Scilab code Exa 4.18** Show TE01 mode propagates under given conditions

```

1 //Caption:Show TE01 mode propagates under given
   conditions
2 //Exa:4.18
3 clc;
4 clear;
5 close;
6 a=1.5;//in cm
7 b=1;//in cm
8 e_r=4;//dielectric
9 c=3*10^10;//in cm/s
10 wl_c=2*b;
11 f_c=c/wl_c;
12 f_imp=6*10^9;//impressed frequency (in Hz)
13 wl_air=c/f_imp;
14 //Inserting dielectric:
15 wl_dielec=wl_air/sqrt(e_r);
16 if(wl_dielec>wl_c)
17     disp('    TE01 can propagate');
18 else
19     disp('    TE01 cannot propagate');
20 end

```

---

**Scilab code Exa 4.19** Calculate the amount of attenuation if signal of frequency is 6GHz

```
1 //Caption: Calculate the amount of attenuation if
   signal of frequency is 6GHz
2 //Exa:4.19
3 clc;
4 clear;
5 close;
6 u=4*%pi*10^-7;
7 e=8.85*10^-12;
8 c=3*10^10; //in cm/s
9 f=6*10^9; //in Hz
10 a=1.5; //in cm
11 b=1; //in cm
12 //For TE10 mode:
13 m=1;
14 n=0;
15 wl_c=2*a;
16 f_c=c/wl_c;
17 t_1=(m*%pi/a)^2;
18 t_2=(n*%pi/b)^2;
19 t_3=((2*%pi*f)^2)*u*e);
20 a=sqrt(t_1+t_2-t_3); //in neper/m
21 disp(a*20/log(10), 'Attenuation (in dB/m) =');
```

---

**Scilab code Exa 4.20** Calculate the maximum power handling capacity

```
1 //Caption: Calculate the maximum power handling
   capacity
2 //Exa:4.21
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 f=9*10^9; //inHz
8 a=3; //in cm
9 b=1; //in cm
10 E_max=3000; //in V/cm
11 wl_o=c/f;
12 wl_c=2*a; //in TE10
13 wl_g=ceil (wl_o/sqrt(1-(wl_o/wl_c)^2));
14 P_max=(6.63*10^-4)*E_max^2*a*b*(wl_o/wl_g);
15 disp(P_max/1000, 'Maximum power for rectangular
   waveguide (in kilowatts)=');
```

---

**Scilab code Exa 4.21** Calculate the maximum power

```
1 //Caption: Calculate the maximum power
2 //Exa:4.21
```

```

3  clc;
4  clear;
5  close;
6  c=3*10^10; //in cm/s
7  f=9*10^9; //inHz
8  E_max=300; //in V/cm
9  d=5;
10 wl_o=c/f;
11 //For TE11
12 wl_c=d*%pi/1.841;
13 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
14 P_max=0.498*E_max^2*d^2*(wl_o/wl_g);
15 disp(P_max, 'Maximum power (in watts) =');

```

---

**Scilab code Exa 4.22** Calculate the peak value of electric field occurring in the waveguide

```

1 //Caption: Calculate the peak value of electric field
   occurring in the waveguide
2 //Exa:4.22
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 f=30*10^9; //inHz
8 a=1; //in cm
9 b=1;
10 P_max=746; //in watts
11 wl_o=c/f;
12 wl_c=2*a;
13 Z=120*%pi/sqrt(1-(wl_o/wl_c)^2);

```

```
14 E_max=sqrt(P_max*4*Z/(a*b/10000));
15 disp(E_max/1000,'Peak value of electric field (in kV
    /m) =');
```

---

**Scilab code Exa 4.23** Calculate the breakdown power of air filled rectangular waveguide for dominant mode

```
1 //Caption: Calculate the breakdown power of air
    filled rectangular waveguide for dominant mode at
    9.375 GHz.
2 //Exa:4.23
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10;//in cm/s
8 a=2.3;//in cm
9 b=1;//in cm
10 f=9.375*10^9;//in Hz
11 wl_o=c/f;
12 P_bd_TE11=597*2.3*1*{1-{wl_o/(2*a)}^2}^0.5;
13 disp(P_bd_TE11,'Breakdown power for dominant mode (
    in kW) =');
```

---

**Scilab code Exa 4.24** Calculate the breakdown power of circular waveguide

```
1 //Caption: Calculate the breakdown power of circular
   waveguide
2 //Exa:4.24
3 clc;
4 clear;
5 close;
6 //Given:
7 d=5; //in cm
8 c=3*10^10; //in cm/s
9 f=9*10^9; //inHz
10 //Dominant mode is TE11:
11 wl_o=c/f;
12 wl_c=%pi*d/1.841;
13 f_c=c/wl_c;
14 P_bd_TE11=1790*(d/2)^2*[1-{f_c/f}^2]^0.5;
15 disp(P_bd_TE11/1000, 'Breakdown power (in kW) =');
```

---

# Chapter 5

## Cavity Resonators

Scilab code Exa 5.1 Determine the minimum distance between two end plates

```
1 //Caption:Determine the minimum distance between two
   end plates
2 //Exa:5.1
3 clc;
4 clear;
5 close;
6 //Given:
7 a=3;//in cm
8 c=3*10^10;//in cm/s
9 f=10*10^9;//in Hz
10 P_01=2.405;
11 d=%pi/sqrt(f^2*4*%pi^2/c^2-(P_01/a)^2);
12 disp(d,'Minimum distance (in cm) =');
```

---



**Scilab code Exa 5.2** Calculate the lowest frequency of a rectangular cavity resonator

```
1 //Caption: Calculate the lowest frequency of a
   rectangular cavity resonator
2 //Exa:5.2
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=2; //in cm
9 b=1; //in cm
10 d=3; //in cm
11 disp('Dominant mode is TE101');
12 m=1;
13 n=0;
14 p=1;
15 f=(c/2)*[(m/a)^2+(n/b)^2+(p/d)^2]^0.5;
16 disp(f/10^9, 'Lowest resonant frequency (in GHz) =');
```

---

**Scilab code Exa 5.3** Calculate the resonant frequency of a circular cavity resonator

```
1 //Caption: Calculate the resonant frequency of a
   circular cavity resonator
2 //Exa:5.3
3 clc;
4 clear;
5 close;
6 //Given:
```

```

7 d=12.5; //diameter(in cm)
8 c=3*10^10; //in cm/s
9 l=5; //length(in cm)
10 a=d/2;
11 //For TM012 mode:
12 n=0;
13 m=1;
14 p=2;
15 P=2.405;
16 f=(c/(2*pi))*[(P/a)^2+(p*pi/d)^2]^0.5;
17 disp(f/10^9, 'Resonant frequency (in GHz) =');
18
19 //Answer in book in wrongly given as 6.27GHz

```

---

**Scilab code Exa 5.4** Calculate the resonant frequency of a circular cavity resonator

```

1 //Caption: Calculate the resonant frequency of a
   circular cavity resonator
2 //Exa:5.4
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=3; //in cm
9 b=2; //in cm
10 d=4; //in cm
11 //For TE101:
12 m=1;
13 n=0;

```

```
14 p=1;
15 f=(c/2)*[(m/a)^2+(n/b)^2+(p/d)^2]^0.5;
16 disp(f/10^9, 'Resonant frequency (in GHz) =');
```

---

# Chapter 6

## Microwave Components

**Scilab code Exa 6.2** Find the distance that the position of port 1 should be shifted

```
1 //Caption:Find the distance that the position of
   port 1 should be shifted .
2 //Exa:6.2
3 clc;
4 clear;
5 close;
6 Beeta=34.3;//in rad/m
7 // S=[0,0.5*%e^(%i*53.13);0.5*%e^(%i*53.13) ,0];
8 // S'=[0,0.5*%e^(%i*53.13-x);0.5*%e^(%i*53.13-x) ,0];
9 //For S12& S21 to be real ,
10 x=53.5;//in degrees
11 x_rad=53.5*%pi/180;
12 l=x_rad/Beeta;
13 disp(l*100, 'Distance (in cm)=');
```

---

**Scilab code Exa 6.3** Determine the scattering parameters for 10 dB direction coupler

```
1 //Caption:Determine the scattering parameters for 10
    dB direction coupler
2 //Exa:6.3
3 clc;
4 clear;
5 close;
6 D=30;//in dB
7 VSWR=1;
8 C=10;
9 //p1_p4 = p1/p4
10 p1_p4=10^(C/-10);
11 S_41=sqrt(p1_p4);
12 S_14=S_41;//As matched & lossless
13 S_31=S_41^2/10^(D/10);
14 S_11=(VSWR-1)/(VSWR+1);
15 S_22=S_11;
16 S_44=S_11;
17 S_33=S_11;
18 S_21=sqrt(1-0.1-10^-4);
19 S_12=S_21;
20 S_34=sqrt(1-0.1-10^-4);
21 S_43=S_34;
22 S_24=sqrt(1-0.1-S_34^2);
23 S_42=S_24;
24 S_23=S_41;
25 S_32=S_23;
26 S_13=S_31;
```

```
27 S=[S_11,S_12,S_13,S_14;S_21,S_22,S_23,S_24;S_31,S_32
    ,S_33,S_34;S_41,S_42,S_43,S_44];
28 disp(S,'Required Scattering Parameters are');
```

---

**Scilab code Exa 6.4** Determine the powers in the remaining ports

```
1 //Caption:Determine the powers in the remaining
  ports
2 //Exa:6.4
3 clc;
4 clear;
5 close;
6 a_2=0;
7 a_3=0;
8 a_1=32; //in mW
9 b_1=(a_1/2^2)+(a_2/-2)+(a_3/sqrt(2));
10 b_2=(a_1/(-2)^2)+(a_2/-2)+(a_3/sqrt(2));
11 b_3=(a_1/2)+(a_2/sqrt(2)+(a_3/-sqrt(2));
12 disp(b_1,'Power at port1 (in mW)=');
13 disp(b_2,'Power at port2 (in mW) =');
14 disp(b_3,'Power at port3 (in mW) =');
```

---

**Scilab code Exa 6.5** Determine the powers in the remaining ports

```

1 //Caption:Determine the powers in the remaining
  ports
2 //Exa:6.5
3 clc;
4 clear;
5 close;
6 b_1=20;
7 b_2=20;
8 p_1=abs((60-50)/(60+50));
9 p_2=abs((75-50)/(75+50));
10 P_1=b_1*(1-p_1^2)/2;
11 P_2=b_2*(1-p_2^2)/2;
12 disp(P_1,'Power in port1 (in mW) =');
13 disp(P_2,'Power in port2 (in mW) =');

```

---

**Scilab code Exa 6.6** Determine the powers reflected at port 3 and power divisions at other ports

```

1 //Caption:Determine the powers reflected at port 3 &
  power divisions at other ports.
2 //Exa:6.6
3 clc;
4 clear;
5 close;
6 p_1=0.5;
7 p_2=0.6;
8 p_4=0.8;
9 b_1=0.6566;
10 b_2=0.7576;
11 b_3=0.6536;
12 b_4=0.00797;

```

```
13 a_1=p_1*b_1;
14 a_2=p_2*b_2;
15 a_3=1; //in Watts
16 a_4=p_4*b_4;
17 disp(b_1^2, 'Power at port 1(in W)=');
18 disp(b_2^2, 'Power at port 2(in W)=');
19 disp(b_3^2, 'Power at port 3(in W)=');
20 disp(b_4^2, 'Power at port 4(in W)=');
```

---

**Scilab code Exa 6.7** Calculate the scattering matrix

```
1 //Caption: Calculate the scattering matrix.
2 //Exa:6.7
3 clc;
4 clear;
5 close;
6 In_loss=0.5; //in dB
7 S_21=10^(-In_loss/20);
8 Isolation=30; //in dB
9 S_12=10^(-Isolation/20);
10 S_11=0;
11 S_22=0;
12 S=[S_11,S_12;S_21,S_22];
13 disp(S, 'Scattering matrix =');
```

---



**Scilab code Exa 6.9** Calculate the scattering matrix

```
1 //Caption:Calculate the scattering matrix.
2 //Exa:6.9
3 clc;
4 clear;
5 close;
6 VSWR=1;
7 In_loss=0.5;//in dB
8 S_21=10^(-In_loss/20);
9 Isolation=20;//in dB
10 S_12=10^(-Isolation/20);
11 S_23=S_12;
12 S_31=S_12;
13 S_32=S_21;
14 S_13=S_21;
15 p=(VSWR-1)/(VSWR+1);
16 S_11=p;
17 S_22=p;
18 S_33=p;
19 S=[S_11,S_12,S_13;S_21,S_22,S_23;S_31,S_32,S_33];
20 disp(S,'Scattering matrix =');
```

---

**Scilab code Exa 6.10** Calculate the scattering matrix

```
1 //Caption:Calculate the scattering matrix.
2 //Exa:6.10
3 clc;
4 clear;
5 close;
6 In_loss=0.5;//insertion loss(in dB)
```

```

7 C=20; //in dB
8 D=35; //in dB
9 Pi_Pf=10^(C/10);
10 Pi=90; //in Watts
11 Pf=Pi/Pi_Pf;
12 Pf_Pb=10^(D/10);
13 Pb=Pf/Pf_Pb;
14 P_rec=(Pi-Pf-Pb); //Power received (in Watts)
15 P_rec_dB=10*log(Pi/P_rec)/log(10);
16 P_rec_eff=P_rec_dB-In_loss; //Effective power
    received (in dB)
17 disp(P_rec_eff, 'Effective power received (in dB)=');

```

---

**Scilab code Exa 6.11** Calculate the directivity and coupling and isolation

```

1 //Caption: Calculate (i)-directivity ,(ii)-coupling ,
    (iii)-isolation
2 //Exa:6.11
3 clc;
4 clear;
5 close;
6 S_13=0.1;
7 S_14=0.05;
8 C=-20*log(S_13)/log(10);
9 D=20*log(S_13/S_14)/log(10);
10 I=C+D;
11 disp(C, 'Coupling (in dB) =');
12 disp(D, 'Directivity (in dB) =');
13 disp(I, 'Isolation (in dB) =');

```

---

**Scilab code Exa 6.12** Calculate the value of VSWR

```
1 //Caption: Calculate the value of VSWR
2 //Exa:6.12
3 clc;
4 clear;
5 close;
6 D=3.5; //distance of seperation (in cm)
7 w_1=2*D; //wavelength
8 d2_d1=2.5; //d2-d1 (in m)
9 S=w_1/(%pi*d2_d1*10^-1);
10 disp(S, 'VSWR =');
```

---

**Scilab code Exa 6.13** Calculate the phase shift of the component

```
1 //Caption: Calculate the phase shift of the component
2 //Exa:6.13
3 clc;
4 clear;
5 close;
6 w_1=7.2; //wavelength (in cm)
7 x=10.5-9.3;
8 Phase_shift=(2*%pi*x)/(w_1);
```

```
9 disp(Phase_shift*180/%pi, 'Phase Shift (in degree) ='  
);
```

---

# Chapter 7

## Microwave Measurements

Scilab code Exa 7.1 Calculate the SWR of the transmission line

```
1 //Caption: Calculate the SWR of the transmission line
2 //Exa:7.1
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=4; //in cm
9 b=2.5; //in cm
10 f=10*10^9; //in Hz
11 d=0.1; //distance between 2 minimum power points (in
      cm)
12 //For TE10 mode:
13 wl_c=2*a;
14 wl_o=c/f;
15 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
16 S=wl_g/(%pi*d);
17 disp(S, 'Voltage standing wave ratio =');
```

---

**Scilab code Exa 7.2** Calculate the SWR of the main waveguide

```
1 //Caption: Calculate the SWR of the main waveguide
2 //Exa:7.2
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=300; //in mW
8 P_r=10; //in mW
9 p=sqrt(P_r/P_i);
10 S=(1+p)/(1-p);
11 disp(S, 'Voltage standing wave ratio =');
```

---

**Scilab code Exa 7.3** Calculate the SWR of the waveguide

```
1 //Caption: Calculate the SWR of the waveguide
2 //Exa:7.3
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=2.5; //in mW
8 P_r=0.15; //in mW
```

```
9 p=sqrt(P_r/P_i);
10 S=(1+p)/(1-p);
11 disp(S, 'Voltage standing wave ratio =');
```

---

**Scilab code Exa 7.4** Calculate the value of reflected power

```
1 //Caption: Calculate the value of reflected power
2 //Exa:7.4
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=4.5; //in mW
8 S=2; //VSWR
9 C=30; //in dB
10 p=(S-1)/(S+1);
11 P_f=P_i/(10^(C/10));
12 P_r=p^2*P_i;
13 disp(P_r, 'Reflected power (in watts) =');
```

---

# Chapter 8

## Microwave Tubes and Circuits

**Scilab code Exa 8.1** Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density

```
1 //Caption: Calculate (i)-dc electron velocity ,(ii)-dc
   phase constant , (iii)-plasma frequency , (iv)-
   reduced plasma frequency for R=0.4, (v)-dc beam
   current beam density , (vi)-instantaneous beam
   current density
2 //Exa:8.1
3 clc;
4 clear;
5 close;
6 V_o=14.5*10^3; //in volts
7 I_o=1.4; //in A
8 f=10*10^9; //in Hz
9 p_o=10^-6; //in c/m^3
10 p=10^-8; //in c/m^3
11 v=10^5; //in m/s
12 R=0.4;
13 v_o=0.593*10^6*sqrt(V_o);
14 k=2*%pi*f/v_o;
15 w_p=[1.759*10^11*(10^-6/(8.854*10^-12))]^0.5;
```



```

16 w_q=R*w_p;
17 J_o=p_o*v_o;
18 J=p*v_o+p_o*v;
19 disp(v_o,'Dc electron velocity (in m/s) =');
20 disp(k,'Dc phase constant (in rad/s) =');
21 disp(w_p,'Plasma frequency (in rad/s) =');
22 disp(w_q,'Reduced plasma frequency (in rad/s) =');
23 disp(J_o,'Dc beam current density (in A/sq. m) =');
24 disp(J,'Instantaneous beam current density(in A/sq.
    m) =');
25
26 //Answer in book are wrongly written as: (Dc phase
    constant =1.41* 10^8 rad/sec)

```

---

**Scilab code Exa 8.2** Calculate the input rms voltage and output rms voltage and power delivered to load

```

1 //Caption: Calculate (i)-input rms voltage ,(ii)-
    output rms voltage , (iii)-power delivered to load
2 //Exa:8.2
3 clc;
4 clear;
5 close;
6 A_v=15;//in dB
7 P_i=5*10^-3;//in W
8 R_sh_i=30000;//in ohms
9 R_sh_o=40000;//in ohms
10 R_l=20000;//in ohms
11 V_i=sqrt(P_i*R_sh_i);
12 V_o=10^((A_v/20))*12.25;
13 P_out=V_o^2/R_l;

```

```
14 disp(V_i, 'Input rms voltage (in volts) =');
15 disp(V_o, 'Output rms voltage (in volts) =');
16 disp(P_out, 'Power delivered to load (in watts) =');
```

---

**Scilab code Exa 8.3** Calculate the input power in watts and output power in watts and efficiency

```
1 //Caption: Calculate (i)-input power in watts, (ii)-
   output power in watts, (iii)-efficiency
2 //Exa:8.3
3 clc;
4 clear;
5 close;
6 n=2;
7 V_o=300; //in volts
8 I_o=20*10^-3; //in A
9 V_i=40; //in volts
10 J=1.25; //J(X')
11 P_dc=V_o*I_o;
12 P_ac=2*V_o*I_o*J/(2*n*%pi-%pi/2);
13 eff=(P_ac/P_dc)*100;
14 disp(P_dc, 'Input power (in watts) =');
15 disp(P_ac, 'Output power (in watts) =');
16 disp(eff, 'Efficiency (in percent) =');
```

---

**Scilab code Exa 8.4** Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB

```

1 //Caption: Calculate (i)-electron velocity ,(ii)-dc
  transit time, (iii)-input voltage for maximum
  output voltage ,(iv)-voltage gain in dB
2 //Exa:8.4
3 clc;
4 clear;
5 close;
6 V_o=900; //in volts
7 I_o=30*10^-3; //in A
8 f=8*10^9; //in Hz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohm
12 v_o=0.593*10^6*sqrt(V_o);
13 T_o=l/v_o;
14 Theeta_o=(2*%pi*f)*T_o; //Transit angles between
  cavities(in radian)
15 Theeta_g=(2*%pi*f)*d/v_o; //Average gap transit angle
  (in radian)
16 b=sin(Theeta_g/2)/(Theeta_g/2);
17 V_in_max=V_o*3.68/(b*Theeta_o);
18 //As, {J(X)/X=0.582}
19 A_r=b^2*Theeta_o*0.582*R_sh/(30*10^3*1.841);
20 disp(v_o, 'Electron velocity (in m/s) =');
21 disp(T_o, 'Dc Transit Time (in sec)=');
22 disp(V_in_max, 'Maximum input voltage (in volts) =');
23 disp(A_r, 'Voltage gain (in dB) =');

```

---

**Scilab code Exa 8.5** Calculate the input microwave voltage and voltage gain and efficiency of amplifier and beam loading conductance

```

1 //Caption: Calculate (i)-i/p microwave voltage ,(ii)-
    voltage gain, (iii)-efficiency of amplifier ,(iv)-
    beam loading conductance
2 //Exa:8.5
3 clc;
4 clear;
5 close;
6 V_o=1200; //in volts
7 I_o=28*10^-3; //in A
8 f=8*10^9; //in Hz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohms
12 V_p_max=1200*3.68*0.593*10^6*sqrt(V_o)/(2*pi*f*l);
13 Theeta_g=(2*pi*f)*d/(0.593*10^6*sqrt(V_o)); //
    transit angle (in rad)
14 beeta=sin(Theeta_g/2)/(Theeta_g/2);
15 V_i_max=V_p_max/beeta;
16 Beeta_o=0.768;
17 J=0.582; //J(X)
18 A_v=(Beeta_o)^2*97.88*J*R_sh/(1200/(28*10^-3*1.841))
    ; //calculating voltage gain
19 eff=[0.58*[2*28*10^-3*J*Beeta_o*R_sh]/V_o]*100; //
    calculating efficiency
20 G_o=23.3*10^-6;
21 G_b=(G_o/2)*{Beeta_o^2-Beeta_o*cos(Theeta_g)}; //beam
    loading conductance
22 R_b=1/(G_b*1000); //beam loading resistance (in kilo
    ohms)
23 disp(V_i_max, 'Input microwave voltage (in volts) =');
24 disp(A_v, 'Voltage gain =');
25 disp(ef, 'Efficiency of amplifier (in percentage) =
    ');
26 disp(R_b, 'Beam loading resistance (in kilo ohms) =');
27

```

```
28 //Answer in book is wrongly given as: Voltage gain
    =17.034
```

---

**Scilab code Exa 8.6** Calculate the value of repeller voltage and beam current necessary to give gap voltage of 200V and electronic efficiency

```
1 //Caption: Calculate (i)-value of repeller voltage
    V_r , (ii)-beam current necessary to give gap
    voltage of 200V, (iii)-electronic efficiency
2 //Exa:8.6
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 V_o=500; //in volts
8 R_sh=20*10^3; //in ohms
9 f=8*10^9; //inHz
10 w=2*%pi*f;
11 n=2; //mode
12 L=0.001; //spacing between repeller & cavity (in m)
13 x=0.023;
14 volt_diff=sqrt(V_o*(x));
15 V_r=volt_diff+V_o; //repeller volatge
16 Beeta_o=1; //Assuming
17 J=0.582;
18 V_1=200; //given (in volts)
19 I_o=V_1/(R_sh*2*J);
20 Theeta_o=2*%pi*f*J*10^6*2*10^-3*sqrt(V_o)
    /(1.579*10^11*(V_r+V_o));
21 X=V_1*Theeta_o/(2*V_o); //X'
22 j=0.84; //J(X')
```

```

23 eff=[2*j/(2*pi*2-%pi/2)]*100;
24 disp(V_r,'Repeller voltage(in volts) =');
25 disp(I_o,'Necessary beam current (in Amp.s) =');
26 disp(eff,'Effeciency (in percentage) =');

```

---

**Scilab code Exa 8.7** Calculate the efficiency of reflex klystron and total output power in mW and power delivered to load

```

1 //Caption: Calculate (i)-efficiency of reflex
   klystron ,(ii)-total output power in mW, (iii)-
   power delivered to load
2 //Exa:8.7
3 clc;
4 clear;
5 close;
6 P_dc_in=40;//in mW
7 ratio=0.278;//V_1/V_o;
8 n=1;
9 X=ratio*(2*n*pi-%pi/2);
10 J=2.35;
11 eff=ratio*J*100;//in percentage
12 P_out= 8.91*P_dc_in/100;
13 P_load=3.564*80/100;
14 disp(eff,'Effeciency (in percentage) =');
15 disp(P_out,'Total power output (in mW) =');
16 disp(P_load,'Power delivered to load (in mW) =');

```

---

**Scilab code Exa 8.8** Calculate the Hull cutoff voltage and cutoff magnetic flux density if beam voltage is 6000V and cyclotron frequency in GHz

```

1 //Caption: Calculate (i)-Hull cut-off voltage ,(ii)-
    cut-off magnetic flux density if beam voltage V_o
    is 6000V, (iii)-cyclotron frequency in GHz
2 //Exa:8.8
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 R_a=0.15; //in m
8 R_o=0.45; //in m
9 B_o=1.2*10^-3; //in weber/m^2
10 V_o={(e_m_ratio)*B_o^2*R_o^2*[1-(R_a/R_o)^2]^2}/8;
11 //Given:
12 V=6000; //in volts
13 B_c=sqrt(8*V/e_m_ratio)/[[1-(R_a/R_o)^2]*(R_o)]; //in
    weber/m^2
14 w_c=(e_m_ratio)*B_o;
15 f_c=w_c/(2*%pi); //in Hz
16 disp(V_o, 'Cut-off voltage (in volts) =');
17 disp(B_c*10^5, 'Cut-off magnetic flux density (in
    milli weber/sq. m) =');
18 disp(f_c*10^-9, 'Cyclotron frequency (in GHz) =');
19
20 //Answer in book is wrongly given as: f_c=0.336Hz &
    V_o=50.666 kV

```

---

**Scilab code Exa 8.9** Calculate the Axial phase velocity and Anode voltage at which TWT can be operated for useful gain

```
1 //Caption: Calculate (i)-Axial phase velocity ,(ii)-
    Anode voltage at which TWT can be operated for
    useful gain
2 //Exa:8.9
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 c=3*10^8; //in m/s
8 d=0.002; //diameter(in m)
9 pitch=(1/50)/100; //As,50 turns per cm (in m)
10 circum=%pi*d;
11 v_p=c*pitch/circum;
12 V_o=v_p^2/(2*e_m_ratio);
13 disp(v_p,'Axial phase velocity (in m/s) =');
14 disp(V_o,'Anode Voltage (in kV) =');
15
16 //Answer in book is wrongly given as V_o=25.92 V
```

---

**Scilab code Exa 8.10** Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB



```

1 //Caption: Calculate (i)-electron velocity ,(ii)-dc
    transit time, (iii)-input voltage for maximum
    output voltage ,(iv)-voltage gain in dB
2 //Exa:8.10
3 clc;
4 clear;
5 close;
6 V_o=900; //in volts
7 I_o=30*10^-3; //in A
8 f=8*10^9; //in Hz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohm
12 v_o=0.593*10^6*sqrt(V_o);
13 T_o=l/v_o;
14 Theeta_o=(2*%pi*f)*T_o; //Transit angles between
    cavities (in radian)
15 Theeta_g=(2*%pi*f)*d/v_o; //Average gap transit angle
    (in radian)
16 b=sin(Theeta_g/2)/(Theeta_g/2);
17 V_in_max=V_o*3.68/(b*Theeta_o);
18 //As, {J(X)/X=0.582}
19 A_r=b^2*Theeta_o*0.582*R_sh/(30*10^3*1.841);
20 disp(v_o, 'Electron velocity (in m/s) =');
21 disp(T_o, 'Dc Transit Time (in sec)=');
22 disp(V_in_max, 'Maximum input voltage (in volts) =');
23 disp(A_r, 'Voltage gain (in dB) =');

```

---

**Scilab code Exa 8.11** Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density

```

1 //Caption: Calculate (i)-dc electron velocity ,(ii)-dc
  phase constant , (iii)-plasma frequency , (iv)-
  reduced plasma frequency for R=0.5, (v)-dc beam
  current beam density , (vi)-instantaneous beam
  current density
2 //Exa:8.11
3 clc;
4 clear;
5 close;
6 V_o=20*10^3;//in volts
7 I_o=2;//in A
8 f=10*10^9;//in Hz
9 p_o=10^-6;//in c/m^3
10 p=10^-8;//in c/m^3
11 v=10^5;//in m/s
12 R=0.5;
13 v_o=0.593*10^6*sqrt(V_o);
14 k=2*%pi*f/v_o;
15 w_p=[1.759*10^11*(10^-6/(8.854*10^-12))]^0.5;
16 w_q=R*w_p;
17 J_o=p_o*v_o;
18 J=p*v_o-p_o*v;
19 disp(v_o,'Dc electron velocity (in m/s) =');
20 disp(k,'Dc phase constant (in rad/s) =');
21 disp(w_p,'Plasma frequency (in rad/s) =');
22 disp(w_q,'Reduced plasma frequency (in rad/s) =');
23 disp(J_o,'Dc beam current density (in A/sq. m) =');
24 disp(J,'Instantaneous beam current density(in A/sq.
  m) =');

```

---

**Scilab code Exa 8.12** Calculate the gap transit angle

```

1 //Caption: Calculate the gap transit angle
2 //Exa:8.12
3 clc;
4 clear;
5 close;
6 V_o=1000; //Anode voltage(in volts)
7 gap=0.002; //in m
8 f=5*10^9; //in Hz
9 L=2.463*10^-3; //length of drift region (in m)
10 u_o=5.93*10^5*sqrt(V_o); //in m/s
11 Theeta_g=2*%pi*f*2*10^-3/u_o; //radians
12 disp(Theeta_g, 'Transit angle(in radians) =');

```

---

**Scilab code Exa 8.13** Calculate the input rf voltage and voltage gain and efficiency

```

1 //Caption: Calculate (i)-i/p rf voltage ,(ii)-voltage
   gain , (iii)-efficiency
2 //Exa:8.13
3 clc;
4 clear;
5 close;
6 V_o=1200; //in volts
7 I_o=30*10^-3; //in A
8 f=10*10^9; //inHz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohms
12 v_o=0.593*10^6*sqrt(V_o);
13 Theeta_o=2*%pi*f*l/(20.54*10^6);
14 X=1.84; //for maximum output power

```

```

15 V_max=2*X*V_o/122.347;
16 Theeta_g=122.347*10^-3/(4*10^-2);
17 Beeta_i=sin(Theeta_g/2)/(Theeta_g/2);
18 V_1_max=V_max/Beeta_i;
19 J=0.58;
20 Beeta_o=Beeta_i;
21 I_2=2*I_o*J;
22 V_2=Beeta_o*I_2*R_sh;
23 A_v=V_2/V_1_max;//in dB
24 eff=0.58*(V_2/V_o)*100;//in percentage
25 disp(V_1_max,'Input rf voltage(in volts) =');
26 disp(A_v,'Voltage gain (in dB) =');
27 disp(eff,'Maximum efficiency (in percentage) =');
28
29 //Answer in book is wrongly given as: A_v=24.33 dB

```

---

**Scilab code Exa 8.14** Calculate the cyclotron angular frequency and cut-off voltage and cutoff magnetic flux

```

1 //Caption: Calculate (i)-cyclotron angular frequency ,
   (ii)-cut-off voltage , (iii)-cut-off magnetic
   flux
2 //Exa:8.14
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11;//(e/m)
7 a=0.04;
8 b=0.08;
9 V_o=30*10^3;//in volts
10 I_o=80;//in A

```

```

11 B_o=0.01; //in weber/sq.m
12 w=(e_m_ratio)*B_o;
13 disp(w, 'Cyclotron angular frequency ( in rad/s) =');
14 V_c={(e_m_ratio)*B_o^2*b^2*[1-(a/b)^2]^2}/8;
15 disp(V_c, 'Cut-off voltage (in volts) =');
16 B_c=sqrt(8*V_o/e_m_ratio)/[[1-(a/b)^2]*(b)]; //in
    weber/m^2
17 disp(B_c*10^3, 'Cut-off magnetic flux density (in
    milli weber/sq. m) =');

```

---

**Scilab code Exa 8.15** Calculate the input power and output power in watts and efficiency

```

1 //Caption: Calculate (i)-input power ,(ii)-output
    power in watts , (iii)-efficiency
2 //Exa:8.15
3 clc;
4 clear;
5 close;
6 n=2;
7 V_o=280; //in volts
8 I_o=22*10^-3; //in A
9 V_i=30; //in volts
10 J=1.25; //J(X')
11 P_dc=V_o*I_o;
12 P_ac=2*V_o*I_o*J/(2*n*%pi-%pi/2);
13 eff=(P_ac/P_dc)*100;
14 disp(P_dc, 'Input power (in watts) =');
15 disp(P_ac, 'Output power (in watts) =');
16 disp(eff, 'Efficiency (in percent) =');

```

---

**Scilab code Exa 8.16** Calculate the repeller voltage and beam current necessary to give gap voltage of 200V

```
1 //Caption: Calculate (i)-repeller voltage V_r ,(ii)-
   beam current necessary to give gap voltage of 200
   V
2 //Exa:8.16
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 V_o=300; //in volts
8 R_sh=20*10^3; //in ohms
9 f=8*10^9; //inHz
10 w=2*%pi*f;
11 n=2; //mode
12 L=0.001; //spacing between repeller & cavity (in m)
13 x=(e_m_ratio)*(2*%pi*n-%pi/2)^2/(8*w^2*L^2);
14 volt_diff=sqrt(V_o/(x));
15 V_r=(volt_diff)+V_o; //repeller volatge
16 J=0.582;
17 V_1=200; //given (in volts)
18 I_o=V_1/(R_sh*2*J);
19 disp(V_r, 'Repeller voltage (in volts) =');
20 disp(I_o*10^3, 'Necessary beam current (in milliAmp.s
   ) =');
```

---



# Chapter 9

## Solid State Microwave Devices

**Scilab code Exa 9.1** Calculate i repeller voltage Vr ii beam current necessary to give gap voltage of 200V

```
1 //Caption: Calculate operating frequency of IMPATT
   diode
2 //Exa:9.1
3 clc;
4 clear;
5 close;
6 v_d=10^7*10^-2; //drift velocity (in m/s)
7 L=2*10^-6; //drift length (in m)
8 f=v_d/(2*L); //in Hz
9 disp(f/10^9, 'Operating Frequency (in GHz) =');
```

---

**Scilab code Exa 9.2** Determine threshold electric field

```
1 //Caption: Determine threshold electric field
```



```

2 //Exa:9_2
3 clc;
4 clear;
5 close;
6 f=10*10^9; //in Hz
7 L=75*10^-6; //Device length (in m)
8 V=25; //Voltage pulse amplified (in volts)
9 E_th=V/L;
10 disp(E_th, 'Threshold Electric field (in kV/cm) =');

```

---

**Scilab code Exa 9.3** Calculate the power gain in dB and power gain if it is USB converter

```

1 //Caption: Calculate (i)-power gain in dB ,(ii)-power
   gain if it is USB converter.
2 //Exa:9.3
3 clc;
4 clear;
5 close;
6 f_s=2*10^9; //in Hz
7 f_p=12*10^9; //in Hz
8 R_i=16;
9 R_s=1000;
10 A_p=10*log((f_p-f_s)/f_s);
11 A_p_usb=10*log((f_p+f_s)/f_s);
12 disp(log(10), 'Power gain (in dB) =');
13 disp(A_p_usb, 'Power gain as USB converter (in dB) =');

```

---

**Scilab code Exa 9.4** Calculate the critical voltage and breakdown voltage and breakdown electric field

```
1 //Caption: Calculate (i)-critical voltage ,(ii)-
    breakdown voltage , (iii)-breakdown electric field
2 //Exa:9.4
3 clc;
4 clear;
5 close;
6 E_s=12.5;
7 E_o=8.85*10^-12;
8 E=E_o*E_s;
9 N=3.2*10^22; //per cubic meter
10 L=8*10^-6; //in m
11 q=1.6*10^-19; //in coulombs
12 V_c=q*N*L^2/(2*E);
13 V_bd=2*V_c;
14 E_bd=V_bd/L;
15 disp(V_c/10^3, 'Critical voltage (in kV) =');
16 disp(V_bd/10^3, 'Breakdown Voltage (in kV) =');
17 disp(E_bd, 'Breakdown Electric field (in V/cm) =');
```

---

**Scilab code Exa 9.5** Calculate the power gain in dB and power gain if it is USB converter

```

1 //Caption: Calculate (i)-power gain in dB ,(ii)-power
   gain if it is USB converter.
2 //Exa:9.5
3 clc;
4 clear;
5 close;
6 N_a=2.5*10^16; //per cubic cm
7 J=33; //in kA/cm^2
8 q=1.6*10^-19;
9 V_z=J/(q*N_a); //Avalanche zone velocity (in cm/s)
10 disp(V_z, 'Avalanche zone velocity (in cm/s) =');

```

---

**Scilab code Exa 9.6** Calculate the power gain in dB

```

1 //Caption: Calculate the power gain in dB
2 //Exa:9.6
3 clc;
4 clear;
5 close;
6 R_neg=25; //in ohm
7 R_load=50; //in ohm
8 G={[- abs(R_neg)-R_load]/[- abs(R_neg)+R_load]}^2;
9 disp(G, 'Power gain =');

```

---

**Scilab code Exa 9.7** Calculate the minimum voltage needed to GUNN effect

```
1 //Caption: Calculate the minimum voltage needed to
   GUNN effect
2 //Exa:9.7
3 clc;
4 clear;
5 close;
6 volt_grad=3.3*10^3; //voltage gradient
7 L=5*10^-4; //in drift length
8 V_min=volt_grad*L; //in volts
9 disp(V_min, 'Minimum voltage needed (in Volts) =');
```

---

**Scilab code Exa 9.8** Calculate the rational frequency and critical velocity of diode

```
1 //Caption: Calculate the rational frequency &
   critical velocity of diode.
2 //Exa:9.8
3 clc;
4 clear;
5 close;
6 v_d=2*10^7; //in cm/s
7 L=20*10^-4; //in cm
8 f=v_d/L;
9 disp(f*10^-9, 'Natural frequency (in GHz) =');
10 critical_field=3.3*10^3;
11 V=L*critical_field;
```

```
12 disp(V, 'Critical voltage (in volts) =');
```

---

**Scilab code Exa 9.9** Calculate the resonant frequency and efficiency

```
1 //Caption: Calculate the resonant frequency &
  efficiency .
2 //Exa:9.9
3 clc;
4 clear;
5 close;
6 L_p=0.5*10^-9; //in H
7 C_j=0.5*10^-12; //in F
8 V_bd=100; //breakdown voltage (in volts)
9 I_bias=100*10^-3; //bias current (in A)
10 I_rf_peak=0.8;
11 R_l=2;
12 f=1/(2*%pi*sqrt(L_p*C_j));
13 eff={(0.5*I_rf_peak^2*R_l)/(V_bd*I_bias)}*100;
14 disp(f*10^-9, 'Resonant frequency (in GHz) =');
15 disp(eff, 'Efficiency (in percentage) =');
```

---

**Scilab code Exa 9.10** Calculate the drift time of carrier and operating frequency of diode

```
1 //Caption: Calculate (i)-drift time of carrier ,(ii)-
  operating frequency of diode
2 //Exa:9.10
```

```

3  clc;
4  clear;
5  close;
6  L=2*10-6; //drift length (in m)
7  v_d=105; //in cm/s
8  drift_time=L/v_d;
9  f=1/(2*drift_time);
10 disp(drift_time, 'Drift time (in sec) =');
11 disp(f*10-9, 'Operating Frequency (in GHz)=');

```

---

**Scilab code Exa 9.11** Calculate the breakdown voltage and breakdown electric field

```

1  //Caption: Calculate (i)-breakdown voltage ,(ii)-
    breakdown electric field.
2  //Exa:9.11
3  clc;
4  clear;
5  close;
6  E_r=11.8;
7  E_o=8.85*10-12;
8  N=3*1021; //in per cubic meter
9  L=6.2*10-6; //in meter
10 q=1.6*10-19; //in coulombs
11 V_bd=q*N*L2/(E_o*E_r);
12 E_bd=V_bd/L;
13 disp(V_bd, 'Breakdown voltage (in volts) =');
14 disp(E_bd, 'Breakdown electric field (in V/m) =');

```

---

**Scilab code Exa 9.12** Calculate the maximum power gain and noise figure and bandwidth

```
1 //Caption: Calculate (i)-maximum power gain in dBs
    ,(ii)-noise figure F in dBs, (iii)-bandwidth for
    r=0.2
2 //Exa:9.12
3 clc;
4 clear;
5 close;
6 ratio=8;
7 r=0.2;
8 r_Q=8;
9 T_d=300; //in Kelvin
10 T_o=300; //in Kelvin
11 X=8;
12 G=(ratio)*X/(1+sqrt(1+X))^2;
13 G_in_dB=(10*log(G))/log(10); //gain
14 disp(G_in_dB, 'Maximum Gain (in dB)=');
15 F=[10*log(1+(2*T_d/T_o)*[(1/(r_Q))+(1/(r_Q)^2)])]/
    log(10); //noise figure
16 disp(F, 'Noise figure (in dB) =');
17 B_W=2*r*sqrt(ratio); //bandwidth
18 disp(B_W, 'bandwidth =');
```

---

**Scilab code Exa 9.13** Calculate the equivalent noise resistance and gain and noise figure and bandwidth

```
1 //Caption: Calculate (i)-equivalent noise resistance ,
   (ii)-gain, (iii)-noise figure, (iv)-bandwidth
2 //Exa:9.13
3 clc;
4 clear;
5 close;
6 f_s=2*10^9; //in Hz
7 f_p=12*10^9; //in Hz
8 f_i=10*10^9; //in Hz
9 f_d=5*10^9; //in Hz
10 R_i=1*10^3; //in ohm
11 R_g=1*10^3; //in ohm
12 R_T_s=1*10^3; //in ohm
13 R_T_i=1*10^3; //in ohm
14 T_d=300; //in Kelvin
15 T_o=300; //in Kelvin
16 w_s=2*%pi*f_s;
17 w_i=2*%pi*f_i;
18 r=0.35;
19 r_Q=10;
20 r_d=300; //in ohm
21 C=0.01*10^-12; //in Farad
22 R=r^2/(w_s*w_i*C^2*R_T_i);
23 a=R/R_T_s;
24 g=((4*f_i*R_g*R_i*a)/(f_s*R_T_s*R_T_i*(1-a)^2)); //
   gain
25 Gain=[10*log(g)]/log(10); //gain in dB
```



```
26 f={1+((2*T_d)/T_o)*[(1/r_Q)+(1/r_Q^2)]}; //noise
    figure
27 F=[10*log(f)]/log(10); //noise figure in dB
28 B_W=(r/2)*sqrt(f_d/(f_s*Gain)); //bandwidth
29 disp(a, 'Equivalent noise resistance (in ohm) =');
30 disp(Gain, 'Gain (in dB) =');
31 disp(F, 'Noise figure (in dB) =');
32 disp(B_W, 'Bandwidth =');
```

---