

Console

```
-->// current is 2A
-->//120V
-->i=2;
-->v=120;
-->// v=I*R where R is the resistance in Ohms
-->r=v/i;
-->disp("r=")

r=
-->disp(r)
60.

-->units='Ohms'
units =
Ohms

-->r=[string(r) units];
-->disp(r)
!60 Ohms !
```